

ACTION TENTS & PROMOTIONS

A Leader in Quality and Service

40X40

Pole Tent Assembly Instructions:

1. Unfold tent and lay flat on the ground, making sure tent is square. Lace tent together from center to the edge and tie three knots at the end.
2. At corners and sides of tent, stakes should be driven into the ground five to six feet away from the edge of the tent in correspondence to each rope.
3. Tie ropes on stakes, leaving two to three feet of slack in your ropes.
4. Insert side poles into rings at each corner and stand upright.
5. Tighten ropes at each corner, making sure to keep the tent straight.
6. Insert remaining side poles into rings and tighten ropes snugly.
7. Insert center pole(s) and stand upright.
8. Tighten all ropes securely. (*Do Not tighten ropes by driving stakes further into the ground!)
9. Snap on sidewall if desired.

